



Applicable models:
LSCM2
LSCM3 LSBM3
LSCM4 LSBM4
LSCM5 LSBM5
LSCM6 LSBM6



1. Unplug the LED from the gantry wall



2. Remove the old LED from the gantry by pulling it down out of the clips, and clip in the new LED



3. Plug the new LED into the gantry wall

